

LEAD ALTERNATIVE PRODUCT SMOOTH & TEXTURED FINISH

INSTALLATION

1. Ensure all surfaces to receive the Easy-Trim Lead R are clean, dry and free of any contamination.
2. All laps should be 75mm min, with pressure applied using a roller.
3. Fold Easy-Trim Lead R into the brickwork joints or 25mm chase cut into the upstand, where it's not possible to do this, apply a sealant along the top edges to ensure the installation is watertight, with a cover flashing.
4. Easy-Trim Lead R can easily be cut with a snap off knife or scissors.
5. Cover slates at top edge abutments by 150mm and carefully adhere up the wall by 75mm.
6. On mansard roofs, install Easy-Trim Lead R with 150mm overlap over lower roof slates. Mechanically fix a lay board and fillet to the upper roof along the eaves, and carefully apply the Easy-Trim Lead R to the lay board and fillet.
7. Remove and make good all unstable surface to receive the Easy-Trim lead R. Where necessary apply a bitumen primer to prepare the surface.



Typical Application

- Abutments
- Dormers
- Soakers
- Valleys
- Valleys and gutters
- Chimneys
- Saddles
- Stepped
- Windows and rooflights